




SHARK ARMY

INSTRUCTION MANUAL

Display and functions

- ① Seconds Hand
- ② Minute Hand
- ③ Hour Hand
- ④ Date



Time setting

Pull the crown out to position III and turn it clockwise or counterclockwise to set the desired time. On some models with a second hand, you can synchronize it with an official time signal (Radio/TV /Internet). When the crown is pulled out in position III, the seconds hand is stopped (Quartz movement only). As soon as the time setting has been synchronized, push the crown back down into position I.

Fast correction of the date

Window calendar

Pull the crown out to position II and turn it clockwise until the correct date is displayed. During this operation, your watch will continue to function normally.

Other functions settings

Please contact our distributor or agent.